

## Top Air Deflectors & Side Skirt / Cab Extenders and Sunvisors

	TOP AIR DEFLECTOR	SIDE SKIRT / CAB EXTENDER	'TIPPER SKIRT' / CAB EXTENDER	SUNVISOR Fiberglass / Acrylic
<b>FOTON:</b>				
Auman 2019+	AK151	SK151		SV151F
Aumark C 2013-current narrowcab		N/A		SV140F
Aumark C 2013-2018 widecab BJ1099	AK141	N/A		SV141F
Aumark S 2019+ BJ1078, BJ1088	AK150	N/A		SV150F
<b>FUSO (Mitsubishi):</b>				
Canter narrowcab 2006-2010	AK225	N/A	-	SV119F -
Canter narrowcab 2011+ (FEA)	AK225	N/A	-	SV225F -
Canter widecab 1994-2005	N/A	N/A	-	SV121F -
Canter widecab 2006-10, 2011+ (FEC)	AK113	N/A	-	SV113F
Enduro FA 2017+	AK113	N/A	-	SV113F
Enduro FO FJ FZ 2017+, Daycab			-	SV147F
Enduro FO FJ FZ 2017+, Supercab	AK148	N/A	-	SV147F
Fighter 1995-2007	AK123	SK101-1	-	SV101F
Fighter 1995-2007 Widecab (import)	785AD10	N/A	-	N/A -
Fighter 2007+ DesignLine Bus	AK126		-	-
Fighter 2007+ & 2011+ NARROWCAB (multi height) NOW USE AK123/AK122	AK101	SK101-2	-	SV101F - SV101A
Fighter 2007+ & 2011+ NARROWCAB (TAD 900mm height)	AK123	SK101-2	-	SV101F - SV101A
Fighter 2007+ & 2011+ NARROWCAB (TAD 1250mm height)	AK122	SK101-2	-	SV101F - SV101A
Fighter 2011+ WIDECAB (multi height) NOW USE AK137/AK138	AK133	SK101-2	-	SV133F -
Fighter 2011+ WIDECAB (TAD 900mm height)	AK137	SK101-2	-	SV133F -
Fighter 2011+ WIDECAB (TAD 1200mm height)	AK138	SK101-2	-	SV133F -
Shogun FS/FV Low Roof 370/430 1999-2011 & 2012+ (orange roof marker lamps)	AK104	SK114	SK104T	SV104F
Shogun FS/FV Low Roof 470 1999+ (big mirror model only)	AK104	SK114	-	SV117FBM
Shogun FS/FV Low Roof 470 2012+ EuroHD (white roof marker lights)	AK104	SK117	SK117T	SV117F
Shogun FS/FV High Roof 1999-2011 (orange roof marker lights)	AK114	SK114	SK114T	SV114F
Shogun FS/FV High Roof 1999+ (Big Mirror)	AK114	SK114	SK114T	SV114FBM
Shogun FS/FV High Roof 2012+ EuroHD (white roof marker lamps)	AK114	SK117	SK124T	SV114F
<b>HINO:</b>				
Dutro / 300 (narrowcab) 2001+	N/A	N/A	-	SV119 - Do not ship
Dutro / 300 (widecab) 2003-2011	AK113-modified	N/A	-	
Dutro / 300 (widecab) 2003-2011 (only suit vehicle with visible "A" pillar)	AK113-modified	N/A	-	SV205F
Dutro / 300 (widecab) 2011+ (with visible 'A' pillar)	AK113-modified	N/A	-	SV205F
Dutro / 300 (widecab) 2011+ (withOUT visible 'A' pillar)	AK113-modified	N/A	-	SV206F (coming soon)
FC FD GD 2003+ (narrow 500)	AK209	N/A	-	SV209F
FF FM GH GT 2003+ (widecab 500)	AK208	N/A	-	SV208F
700 2003+	N/A	N/A	-	SV207F = n/a
<b>HYUNDAI:</b>				
HD65 Day-Cab	AK124	N/A	-	SV124F
HD65 Super-Cab	AK125	N/A	-	SV124F
MIGHTY - Day-Cab	AK145	N/A	-	SV145F
MIGHTY - Super-Cab	AK146	N/A	-	SV145F
<b>ISUZU:</b>				
Giga C&E Low Roof pre 2010 (for import mirrors, use SV102F)	AK102	SK102	SK102T	SV102F - SV102A
Giga C&E Low Roof 2011-2022 excluding daycab (SV122F suits NZ New only)	AK102	SK102	SK102T	SV122F - SV102A
Giga C&E Low Roof 2011-2022 daycab only (SV122F suits NZ New only)	AK102 (must modify first)	SK222		SV122F - SV102A
Giga C&E High Roof 1997-2022	AK116	SK102	SK102+SK116T	SV116F - SV116A
Giga Low Roof 2022+	AK220 & AK143	SK226	SK226T	SV226F
Giga High Roof 2022+	AK216	(included with AK216)		SV216F
F Series 1996-2008 Narrowcab (2 wiper)	AK103	SK103	-	SV103F -
F Series 1996-2008 Widecab (3 wiper)	827AD11	N/A	-	SV103WC -
F Series 2008+, Narrow Cab, FS, FR, etc	AK222	SK220	-	SV227F -
F Series 2008+, Narrow Cab, FS, FR, etc (AUSTRALIA - NO FRONT OVERHANG MIRROR)	AK222	SK220	-	SV223F -
F Series 2008+, Narrow Cab Daycab, FS, FR, etc	827AD22a	SK222	-	SV227F -
F Series 2008+, Narrow Cab Daycab, FS, FR, etc (AUSTRALIA - NO FRONT OVERHANG MIRROR)	827AD22a	SK222	-	SV223F -
F Series 2008+, Widecab FV, FT, etc	AK220 (850mm height)	SK220	-	SV226F - SV220A
F Series 2008+, Widecab FV, FT, etc	AK143 (1200mm height)	SK220	-	SV226F - SV220A
F Series 2008+, Widecab FV, FT, etc (AUSTRALIA - NO FRONT OVERHANG MIRROR)	AK220	SK220	-	SV224F - SV220A
N Series Narrowcab 1994-2007, NKR (NZ Roof Cab)				SV115F -
N Series Narrowcab 1994-2007, NKR (flat cab import)	N/A	N/A	-	SV129F - fit Airplex only
N Series Narrowcab 2008+, NL, NM etc	AK221	N/A	-	SV221F -
N Series Widecab 1985-1994, NPR etc	N/A	N/A	-	-
N Series Widecab 1994-2008, NPR etc	N/A	N/A	-	SV112F -
N Series Widecab 2008+, NP NQ NN (also see below option)	AK219 (850mm height)	SK219	-	SV219F -
N Series Widecab 2008+, NP NQ NN (also see above option)	AK142 (1200mm height)	SK219	-	SV219F -
<b>JAC:</b>				
JAC	N/A	N/A	-	SV112F -
<b>KIA:</b>				
K2900	AK120	included	-	SV120F -
<b>MAN:</b>				
all models	no	no	no	no
<b>MITSUBISHI:</b>				
	<i>refer FUSO listings</i>			
<b>NISSAN:</b>				
	<i>refer UD listings</i>			
<b>SCANIA:</b>				
R Series Top Extension	AK130	N/A	-	-
<b>TOYOTA:</b>				
Dyna (narrowcab) 2001+ (standard roofline ONLY, not flat top)	N/A	N/A	-	SV119 - Do not ship
Dyna (widecab) 2003-2011	AK113 (WITH MOD)	N/A	-	
Dyna (widecab) 2003-2011 (only suit vehicle with visible "A" pillar)	AK113 (WITH MOD)	N/A	-	SV205F - SV205A
Dyna (widecab) 2011+	AK113 (WITH MOD) - don't ship			
<b>UD (Nissan UD):</b>				
MK175 / MK211 / K195 NZ new	AK108	N/A	-	SV108F -
MK (narrow cab import 1500mm) also Atlas				
MK 1993-2010	AK107	SK107	-	SV107F -
MK 2011+ (AK131 850mm high)	AK131	SK132	SK132T	SV131F -

MK 2011+ (AK134 600mm high)	AK134	SK132	SK132T	SV131F -
MK 2011+ (AK139 1200mm high)	AK139	SK132	SK132T	SV131F -
PD / PK / Croner (3 wiper) pre 2011	AK106	SK107	-	SV106F -
PD / PK / Croner 2011+ (AK132 800mm high)	AK132	SK132	SK132T	SV132F -
PD / PK / Croner 2011+ (AK136 1200mm high)	AK136	SK132	SK132T	SV132F -
C Series pre 2010	AK105	SK105	SK105T	SV105F - SV804A
CW/GW Series, 'Quon' 2011+	AK118	SK118	SK118T	SV118F -

**VOLVO:**

all models	no	no	no	no
------------	----	----	----	----