






STAINLESS STEEL TRUCK WHEEL TRIMS



PCD Calculator

				
3 STUD	4 STUD	5 STUD	6 STUD	8 STUD
Measure the distance "S" between the centre of 2 stud holes and multiply by 1.154	Measure the distance "S" between the centre of 2 stud holes and multiply by 1.414 OR measure from centre to centre of opposing bolt holes as red arrows above	Measure the distance "S" between the centre of 2 adjacent stud holes and multiply by 1.7012	Measure the distance "S" between the centre of 2 adjacent stud holes and multiply by 2 OR measure from centre to centre of opposing bolt holes as red arrows above	Measure the distance "S" between the centre of 2 adjacent stud holes and multiply by 2.313 OR measure from centre to centre of opposing bolt holes as red arrows above

www.airplex.co.nz

Phone: 0800 AIRPLEX
(0800 247 753)

airplex
car, ute, truck accessories

22.5" Wheel Trims

	Part#	WT1002-S1
	WHEEL LOCATION	Front each
	TUBED / TUBELESS	Tubeless
	SUITS LUG/STUD#	Any
	PCD	Any
	OFFSET	Any
	NUT COVERS	10 integrated
	INSTALL METHOD	Expansion Ring

Removeable Hubo Cap

<p><i>Shallow Dish</i></p> 	Part#	WT1003-S1
	WHEEL LOCATION	Rear each
	TUBED / TUBELESS	Tubeless
	SUITS LUG/STUD#	Any
	PCD	Any
	OFFSET	Any
	NUT COVERS	10 integrated
	INSTALL METHOD	Expansion Ring

Removeable Hubo Cap

<p><i>Deep Dish</i></p> 	Part#	WT1004-S1
	WHEEL LOCATION	Rear each
	TUBED / TUBELESS	Tubeless
	SUITS LUG/STUD#	Any
	PCD	Any
	OFFSET	Any
	NUT COVERS	10 integrated
	INSTALL METHOD	Expansion Ring

Non-Removeable Hubo Cap

22.5" Wheel Trims



RIM SPECS: 22.5" x 11.75"

Part#	WT1046-S1
WHEEL LOCATION	Front each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	10
PCD	335
OFFSET/INSET	130/30
NUT COVERS	No
INSTALL METHOD	Bolt On



Part#	WT1008-S1
WHEEL LOCATION	Rear each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	10
PCD	Any
OFFSET/INSET	Any
NUT COVERS	No
INSTALL METHOD	Expansion Ring



Part#	WT1007-S1
WHEEL LOCATION	Front each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	10
PCD	Any
OFFSET	Any
NUT COVERS	No
INSTALL METHOD	Expansion Ring

22.5" Wheel Trims



RIM SPECS: 22.5" x 11.75"

Part#	WT1047-S1
WHEEL LOCATION	Front each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	10
PCD	335
OFFSET /INSET	120/40
NUT COVERS	NO
INSTALL METHOD	Bolt On



RIM SPECS: 22.5" x 9" or 8"

Part#	WT1009-S1
WHEEL LOCATION	Front each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	10
PCD	335
OFFSET/INSET	130/30
NUT COVERS	NO
INSTALL METHOD	Bolt On



Part#	WT1006-S1
WHEEL LOCATION	Rear each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	Any
PCD	Any
OFFSET	Any
NUT COVERS	NO
INSTALL METHOD	Expansion Ring

22.5" Wheel Trims



Part#	WT1005-S1
WHEEL LOCATION	Front each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	10
PCD	335
OFFSET	Any
NUT COVERS	No
INSTALL METHOD	Lodged Bracket 23mm



Part#	WT1053-S1
WHEEL LOCATION	Front each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	10
PCD	Any
OFFSET	Any
NUT COVERS	No
INSTALL METHOD	Lodged Bracket 33mm



Part#	WT1010-S1
WHEEL LOCATION	Rear each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	10
PCD	
OFFSET/INSET	Any
NUT COVERS	No
INSTALL METHOD	Expansion Ring

22.5" Wheel Trims



Part#	WT1011-S1
WHEEL LOCATION	Rear each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	10
PCD	
OFFSET	Any
NUT COVERS	No
INSTALL METHOD	Expansion Ring

Fit My Vehicle

**Use our
"Fit My Vehicle"
function on our website
to find out what
we do for your vehicle!**

- Vehicle Make - ▾

- Vehicle Model - ▾

- Vehicle Year - ▾

SEARCH

19.5" Wheel Trims



Not suitable for TOPY rims

Part#	WT1014-S1
WHEEL LOCATION	Front each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	Any
PCD	Any
OFFSET	Any
NUT COVERS	8 Integrated
INSTALL METHOD	Expansion Ring



Not suitable for TOPY rims

Part#	WT1016-S1
WHEEL LOCATION	Rear each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	Any
PCD	Any
OFFSET	Any
NUT COVERS	8 Integrated
INSTALL METHOD	Expansion Ring



Not suitable for TOPY rims

Part#	WT1017-S1
WHEEL LOCATION	Rear each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	Any
PCD	Any
OFFSET	Any
NUT COVERS	8 Integrated
INSTALL METHOD	Expansion Ring

19.5" Wheel Trims



Not suitable for TOPY rims

Part#	WT1012-S1
WHEEL LOCATION	Front each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	Any
PCD	Any
OFFSET/INSET	Any
NUT COVERS	No
INSTALL METHOD	Expansion Ring



Not suitable for TOPY rims

Part#	WT1015-S1
WHEEL LOCATION	Rear each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	Any
PCD	Any
OFFSET	Any
NUT COVERS	No
INSTALL METHOD	Expansion Ring



19.5" x 6RW" for Ford F450
dually (accuride wheels no:
29884, 29839, 29584)

Part#	WT1014-S1
WHEEL LOCATION	4 Wheel Set
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	Any
PCD	Any
OFFSET	Any
NUT COVERS	8 Integrated
INSTALL METHOD	Bolt on

19.5" Wheel Trims




19.5" x 6RW" for Ford F450
dually (accuride wheels no.
29884, 29839, 29584)

Part#	WT1054-S1
WHEEL LOCATION	4 Wheel Set
TUBED / TUBELESS	
SUITS LUG/STUD#	10
PCD	
OFFSET/INSET	
NUT COVERS	
INSTALL METHOD	Bolt On

17.5" Wheel Trims

	Part#	WT1018-S1
	WHEEL LOCATION	Front each
	TUBED / TUBELESS	Tubeless
	SUITS LUG/STUD#	Any
	PCD	Any
	OFFSET	Any
	NUT COVERS	NO
	INSTALL METHOD	Expansion Ring

	Part#	WT1019-S1
	WHEEL LOCATION	Front each
	TUBED / TUBELESS	Tubeless
	SUITS LUG/STUD#	Any
	PCD	Any
	OFFSET	Any
	NUT COVERS	6 Integrated
	INSTALL METHOD	Expansion Ring

	Part#	WT1020-S1
	WHEEL LOCATION	Rear each
	TUBED / TUBELESS	Tubeless
	SUITS LUG/STUD#	Any
	PCD	Any
	OFFSET/INSET	Any
	NUT COVERS	NO
	INSTALL METHOD	Expansion Ring

17.5" Wheel Trims



Suits Shallow Dish Rim

Part#	WT1021-S1
WHEEL LOCATION	Rear each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	Any
PCD	Any
OFFSET	Any
NUT COVERS	6 Integrated
INSTALL METHOD	Expansion Ring



Suits Deep Dish Rim

Part#	WT1022-S1
WHEEL LOCATION	Rear each
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	Any
PCD	Any
OFFSET	Any
NUT COVERS	6 Integrated
INSTALL METHOD	Expansion Ring




Rim Specs: 17.5" x 6"

Part#	WT1023-S2
WHEEL LOCATION	4 Wheel Set
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	6
PCD	222.25
OFFSET	127
NUT COVERS	41mm Loose
INSTALL METHOD	Bolt On

17.5" Wheel Trims

 <p>Rim Specs: 17.5" x 6.75"</p>	Part#	WT1024-S2
	WHEEL LOCATION	4 Wheel Set
	TUBED / TUBELESS	
	SUITS LUG/STUD#	6
	PCD	222.25
	OFFSET	135
	NUT COVERS	41mm Loose
	INSTALL METHOD	Bolt On

 <p>Rim Specs: 17.5" x 6"</p>	Part#	WT1025-S1
	WHEEL LOCATION	4 Wheel Set
	TUBED / TUBELESS	Tubeless
	SUITS LUG/STUD#	5
	PCD	203.5
	OFFSET	100.5
	NUT COVERS	41mm Loose
	INSTALL METHOD	Bolt On

	Part#	WT1026-S1
	WHEEL LOCATION	
	TUBED / TUBELESS	
	SUITS LUG/STUD#	
	PCD	
	OFFSET	
	NUT COVERS	
	INSTALL METHOD	

17.5" Wheel Trims

	Part#	WT1027-S1
	WHEEL LOCATION	
	TUBED / TUBELESS	
	SUITS LUG/STUD#	
	PCD	
	OFFSET	
	NUT COVERS	
	INSTALL METHOD	

	Part#	WT1056-S2
	WHEEL LOCATION	
	TUBED / TUBELESS	
	SUITS LUG/STUD#	
	PCD	
	OFFSET	
	NUT COVERS	
	INSTALL METHOD	

	Part#	WT1023-S3
	WHEEL LOCATION	4 Wheel Set
	TUBED / TUBELESS	Tubeless
	SUITS LUG/STUD#	6
	PCD	127
	OFFSET/INSET	222
	NUT COVERS	41mm Loose
	INSTALL METHOD	Bolt On

Rim Specs: 17.5" & 16" x 6"

16" Wheel Trims to suit Mercedes Sprinter

	Part#	WT1052-S1
	WHEEL LOCATION	Front each
	TUBED / TUBELESS	Tubeless
	SUITS LUG/STUD#	Any
	PCD	Any
	OFFSET	Any
	NUT COVERS	Integrated
	INSTALL METHOD	Friction

	Part#	WT1035-S2
	WHEEL LOCATION	Front each
	TUBED / TUBELESS	Tubed
	SUITS LUG/STUD#	6
	PCD	205
	OFFSET	109.5
	NUT COVERS	19mm Loose
	INSTALL METHOD	Bolt On

18 Decorative Holes

	Part#	WT1050-S2
	WHEEL LOCATION	Rear each
	TUBED / TUBELESS	Tubed
	SUITS LUG/STUD#	6
	PCD	205
	OFFSET	109.5
	NUT COVERS	19mm Loose
	INSTALL METHOD	Bolt On

18 Decorative Holes

16" Wheel Trims to suit Mercedes Sprinter



16" x 5.5" Iveco Daily Dually
HEAVY-DUTY 2000+ (not
standard duty truck)

Part#	WT1055-S2
WHEEL LOCATION	4 Wheel Set
TUBED / TUBELESS	Tubed
SUITS LUG/STUD#	6
PCD	205
OFFSET	125
NUT COVERS	27mm Loose
INSTALL METHOD	Bolt On



Mercedes Sprinter,
VW Crafter

Part#	WT1031-S3
WHEEL LOCATION	4 Wheel Set
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	6
PCD	205
OFFSET	
NUT COVERS	Yes
INSTALL METHOD	Nut Extender



Rim Size 16" x 5.50F

Part#	WT1037-S2
WHEEL LOCATION	4 wheel Set
TUBED / TUBELESS	Tubed
SUITS LUG/STUD#	5
PCD	208
OFFSET	115
NUT COVERS	41mm Loose
INSTALL METHOD	Bolt On

16" Wheel Trims

	Part#	WT1057-S5
	WHEEL LOCATION	4 wheel Set
	TUBED / TUBELESS	Either
	SUITS LUG/STUD#	6
	PCD	222.25
	OFFSET	
	NUT COVERS	41mm Loose
	INSTALL METHOD	Bolt On

 <p><i>Mercedes Sprinter, VW Crafter</i></p>	Part#	WT1031-S3
	WHEEL LOCATION	4 Wheel Set
	TUBED / TUBELESS	Tubeless
	SUITS LUG/STUD#	6
	PCD	205
	OFFSET	
	NUT COVERS	Yes
	INSTALL METHOD	Nut Extender

 <p><i>Rim Size 16" x 5.50F</i></p>	Part#	WT1037-S2
	WHEEL LOCATION	4 wheel Set
	TUBED / TUBELESS	Tubed
	SUITS LUG/STUD#	5
	PCD	208
	OFFSET	115
	NUT COVERS	41mm Loose
	INSTALL METHOD	Bolt On

16" Wheel Trims

	Part#	WT1057-S5
	WHEEL LOCATION	4 wheel Set
	TUBED / TUBELESS	Either
	SUITS LUG/STUD#	6
	PCD	222.25
	OFFSET	
	NUT COVERS	41mm Loose
	INSTALL METHOD	Bolt On

	Part#	WT1058-S5
	WHEEL LOCATION	4 Wheel Set
	TUBED / TUBELESS	Either
	SUITS LUG/STUD#	6
	PCD	222.25
	OFFSET	
	NUT COVERS	38mm Loose
	INSTALL METHOD	Bolt On

	Part#	WT1038-S2
	WHEEL LOCATION	4 Wheel Set
	TUBED / TUBELESS	Tubed
	SUITS LUG/STUD#	5
	PCD	208
	OFFSET/INSET	115
	NUT COVERS	38mm Loose
	INSTALL METHOD	Bolt On

eg: Mitsubishi Rosa 2001-2012

Rim Size: 16" x 5.50F

16" Wheel Trims



eg: Mitsubishi Canter, Rosa,
Nissan Civillian

Rim Size: 16" x 5.5"K-115

Part#	WT1041-S1
WHEEL LOCATION	4 Wheel Set
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	5
PCD	207.3
OFFSET	222.4
NUT COVERS	38mm Loose
INSTALL METHOD	Bolt On



eg: Mitsubishi Canter, Rosa,
Nissan Civillian

Rim Size: 16" x 5.5"K-115

Part#	WT1042-S1
WHEEL LOCATION	4 wheel Set
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	5
PCD	207.3
OFFSET	222.4
NUT COVERS	41mm Loose
INSTALL METHOD	Bolt On



Toyota Coaster

Rim Size: 16" x 5.5"OF

Part#	WT1039-S2
WHEEL LOCATION	4 Wheel Set
TUBED / TUBELESS	Tubed
SUITS LUG/STUD#	5
PCD	203.2
OFFSET	115
NUT COVERS	41mm Loose
INSTALL METHOD	Bolt On

16" Wheel Trims

 <p>eg: <i>Isuzu Elf, Toyota Coaster</i></p> <p>Rim Size: 16" x 5.5"OJ</p>	Part#	WT1040-S1
	WHEEL LOCATION	4 Wheel Set
	TUBED / TUBELESS	Tubeless
	SUITS LUG/STUD#	5
	PCD	203.5
	OFFSET	220.85
	NUT COVERS	41mm Loose
	INSTALL METHOD	Bolt On

 <p><i>Hyundai</i></p>	Part#	WT1051-S1
	WHEEL LOCATION	4 Wheel Set
	TUBED / TUBELESS	Tubeless
	SUITS LUG/STUD#	6
	PCD	205
	OFFSET	91
	NUT COVERS	27mm Loose
	INSTALL METHOD	Bolt On

15" Wheel Trims



Part#	WT1043-S1
WHEEL LOCATION	4 Wheel Set
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	5
PCD	207.3
OFFSET/INSET	88.5
NUT COVERS	41mm Loose
INSTALL METHOD	Bolt On



Part#	WT1044-S1
WHEEL LOCATION	4 Wheel Set
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	5
PCD	203.5
OFFSET	90.25
NUT COVERS	41mm Loose
INSTALL METHOD	Bolt On



Part#	WT1045-S1
WHEEL LOCATION	4 wheel Set
TUBED / TUBELESS	Tubeless
SUITS LUG/STUD#	5
PCD	203.5
OFFSET	87
NUT COVERS	41mm Loose
INSTALL METHOD	Bolt On

Lug Nut Covers - Stainless Steel - sold each

	PART#	LNC30
	DIAMETER	30mm
	HEIGHT	43mm
	PART#	LNC32
	DIAMETER	32mm
	HEIGHT	43mm
	PART#	LNC33
	DIAMETER	33mm
	HEIGHT	43mm
	PART#	LNC38x41mm
	DIAMETER	41mm
	HEIGHT	
	PART#	LNC38x52mm
	DIAMETER	38mm
	HEIGHT	52mm
	PART#	LNC41x43mm
	DIAMETER	41mm
	HEIGHT	43mm
	PART#	LNC41x49mm
	DIAMETER	41mm
	HEIGHT	49mm
	PART#	LNC41x63mm
	DIAMETER	41mm
	HEIGHT	63mm

Find us on Facebook & Instagram - @airplexnz



While we have taken every care with the part numbers in this brochure, please always double-check when placing your order.



airplex
car, ute, truck accessories

100%NZ

About Us:



The leading manufacturer and distributor of utility, truck and car accessories in New Zealand. No one has a wider range.



100% New Zealand family owned and operated.



Over 90% of our product is manufactured in New Zealand.



Best product, quality and service.



Contact Details:

Airplex Industries Ltd
21 Saleyards Road
Otahuhu
Auckland 1062
New Zealand



12th May 2022

BRO119

Phone Toll Free: 0800 247 753

Phone: +64 9 276 9826

Fax: +64 9 276 9827

Email: info@airplex.co.nz